

COMPACT DISK PLAYER


# DP-SE7/SE7(G)/SE9

## SERVICE MANUAL

(HM-701)

KENWOOD

©1997-10/B51-5371-00 (K/K) 3191



In compliance with Federal Regulations, following are reproductions of labels on, or inside the product relating to laser product safety.

KENWOOD-Corp. certifies this equipment conforms to DHHS Regulations No. 21 DFR 1040. 10, Chapter 1, Subchapter J.

**DANGER : Laser radiation when open and interlock defeated.  
AVOID DIRECT EXPOSURE TO BEAM**

Illustration is DP-SE7Mtype.

\* Refer to parts list on page 17.

Refer to DP-SA7 service manual (B51-5243-00) if you require Disassembly for repair in detail.

# DP-SE7/SE7(G)/SE9

## CONTENTS / EXTERNAL VIEW

### Contents

CONTENTS / EXTERNAL VIEW .....	2	SCHEMATIC DIAGRAM .....	9
CIRCUIT DESCRIPTION .....	3	EXPLODED VIEW .....	15
ADJUSTMENT .....	6	PARTS LIST .....	17
PC BOARD .....	7	SPECIFICATIONS .....	Back cover




Illustration is DP-SE9.

### System configuration


SYSTEM NAME	RECEIVER	CD PLAYER	SPEAKER
HM-701	R-SE7	DP-SE7	LS-SE7
HM-901	R-SE9	DP-SE9	LS-SE9

# DP-SE7/SE7(G)/SE9

## CIRCUIT DESCRIPTION

### 1. Microprocessor

#### 1-1. Microprocessor periphery block diagram



# DP-SE7/SE7(G)/SE9

## CIRCUIT DESCRIPTION

### 1-2 Pin description

(uPD78044FGF-071 : X25, IC4)

PIN No.	PIN NAME	I/O	DESCRIPTION
1~7	Grid 2G~8G	O	FL Digit control (Grid 2G~8G)
8	Vdd	O	Power supply (+5)
9	SQCK	O	Q-data read clock output.
10	STBY	O	Not use (OPEN)
11	SUBQ	I	Q-data (or SLT SW) input
12	KR 1	I	Key return input 1
13	KR 0	I	Key return input 0
14~16	NC	I	Not use (PULL DOWN)
17	RESET	I	Reset input
18, 19	NC	I	Not use (PULL DOWN)
20	AVss	-	Not use (GND)
21~24	NC	I	Not use (PULL DOWN)
25	SDT	O	Enable output to KAN03
26	SCK	O	Clock output to KAN03
27	S GATE	O	Data output for KAN03
28	NC	I	Not use
29	AVdd	-	Not use (+5V)
30	AVref	-	Not use (GND)
31	DEFECT	I	Scratch disk compel sat
32	XT2	-	Not use (OPEN)
33	Vss	-	GND
34	X1	I	System clock
35	X2	-	System clock
36	RMUTE	O	Analog mute
37	CLK	O	CXD2507AQ clock output
38	LATCH	O	CXD2507AQ latch output
39	DATA	O	CXD2507AQ data output
40	SENSE	I	SENSE/GFS/F.OK input
41	D.S	O	Not use
42	S.DATA	I/O	Serial DATA I/O
43	S.BUSY	I/O	Serial BUSY I/O
44	SCOR	I	Sub-code synch detect
45	NC	I	Not use (PULL DOWN)
46	M.ON	O	Focus lock compensation
47	REMOCON	I	REMOCON
48	Vpp	-	GND
49	CLOSE SW	I	Tray close (L : close)
50	OPEN SW	I	Tray open (L : open)
51	NC	I	Not use (PULL DOWN)
52	Vdd	-	Power supply (+5V)
53	OPEN MOTOR	O	Motor [OPEN] (H : OPEN/T.U.DOWN)
54	CLOSE MOTOR	O	Motor [CLOSE] (H : CLOSE/T.U.UP)
55~64	NC	O	Not use (OPEN)
65~70	Sa~Sf	O	FL Segment (SEG Sa~Sf)
71	Vlrd	-	FL driver power supply (-30V)
72~77	SEG Sg~Sl/KS 5~0	O	FL Segment Sg~Sl and key scan (KS5~KS0)
78, 79	NC	O	Not use (open)
80	GRID 1G	O	FL digit (Grid 1G)

# DP-SE7/SE7(G)/SE9

## CIRCUIT DESCRIPTION

### 2. Test mode

MODE "0 0" : Use for Test or alignment

Setting the test mode : While pressing the "REPEAT" key, plug the AC cord into wall output.

No.	Key	Display	Operation	Remarks
1	PLAY/ PAUSE ▶/■	03	(1)Focus servo .....ON (2) Tracking servo .....OFF (3) Feed servo .....OFF	TE-adjustment
		05	(1) Focus servo .....ON (2) Tracking servo .....ON (3) Feed servo .....ON	F-GAIN / T-GAIN FE-B adjustment
2	UP ►►		All display ON → All display OFF	
3	FB ◀◀	01	Pick manual feed (outside → inside)	Stop mode only Time display goes off
		05	FB operation is available	
4	FF ►►	01	Pick manual feed (inside → outside)	Stop mode only Time display goes off
		05	FF operation is available	
5	STOP ■	01	Pick-up initialize	
6	OPEN / CLOSE ▲		Tray open / close	
7	DOWN ◀◀	01	Cancel the test mode, and return to normal mode.	Play track No.01

# DP-SE7/SE7(G)/SE9

## ADJUSTMENT

No.	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	PLAYER SETTINGS	ALIGNMENT POINTS	ALIGN FOR	FIG.
While pressing the "REPEAT" key, turn the AC ON. { Refer to test mode (MODE 0 0) }							
1	LASER POWER	—	Apply the sensor section of optical power meter on the pickup lens.	Press the PLAY/PAUSE key, then confirm that the LED is "03".	—	On the power from 0.08 to 0.15 mW, when the diffraction grating is correctly aligned with the RF level of 0.6 Vp-p or more.	(a)
2	FOCUS ERROR BIAS	Test disc Type 4	Connect an oscilloscope as follows. CH1 : RF (CN3 pin 1) CH2 : TE (CN3 pin 6)	Press the PLAY/PAUSE key, then confirm that the LED is "05".	FE BIAS VR2	Optimum eye pattern	
3	TRACKING ERROR BALANCE	Test disc Type 4	Connect an oscilloscope as follows. CH1 : RF (CN3 pin 1) CH2 : TE (CN3 pin 6)	Press the PLAY/PAUSE key, then confirm that the LED is "03".	TE BALANCE VR1	Symmetry between upper and lower patterns	
4	TRACKING GAIN	Test disc Type 4 Apply signal of 1.2 kHz, 50mVrms to CN3 pin 5-6.	Connect a LPF to CN3 pin 5-6 to which you connect an oscilloscope or AC voltmeters.	Press the PLAY/PAUSE key, then confirm that the LED is "05".	TRACKING GAIN VR3	Two VTVMs should read the same value.	(e)


Note:

Type 4 disc : SONY YEEDS-18 Test Disc or equivalent.(KTD-0\*)


LPF: Around  $47\text{ k}\Omega + 390\text{ pF}$  or so.

Step 1~4 are in Test Mode.


### (a) Laser power



### (e) Tracking gain



### ALIGNMENT POINTS



A


B

C

D

E



# PC BOARD(Component side view)




Refer to the schematic diagram for the value of resistors and capacitors.


# PC BOARD(Component side view)


**ELECTRIC UNIT**  
**(X25-6000-00) : DP-SE7**  
**(X25-6000-01) : DP-SE9**




**CD PLAYER UNIT**  
**(X32-3400-00)**










DISPLAY UNIT (X14-4520-21) (B/2) : DP-SE7/DP-SE7(G)  
(X14-4530-21) (B/2) : DP-SE9

CN1	MODEL NAME	UNIT No.	4pin	5pin
	DP-SE7/SE7(G)	X14-4520-21	F1	F2
	DP-SE9	X14-4530-21	F2	F1

(X14-4520-21) (A/2) : DP-SE7/DP-SE7(G)  
(X14-4530-21) (B/2) : DP-SE9




11. *What is the primary purpose of the following statement?*


DP-SE9 (X25-6000-01)

DP-SE7 (X25-6000-00)



DP-SE7(G) (X25-6000-00)



DISPLAY UNIT  
(X14-4530-21) (A/2) : DP-SE9




DP-SE7/DP-SE7(G)



**CAUTION:** For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list).  $\Delta$  indicates safety critical components. For continued protection against risk of fire, replace only with same type and rating fuse(s). To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit, before the appliance is returned to the customer).

The DC voltage is an actual reading measured with a high impedance type voltmeter. The measurement value may vary depending on the measuring instruments used or on the product. Refer to the voltage during PLAY unless otherwise specified; The value shown in ( ) is the voltage measured at the moment of STOP.

2SA1534A  
2SA954  
2SC28782SA1586  
2SC4081


2SB1370



2SB1375



TA8409S



DA204U




UN5212




2SK246




CXA1782BQ\*1




KAN03




BA6398FP




M5237L



CXD2507AQ\*1




ICP-N25




# DP-SE7/SE7(G)/SE9

## EXPLODED VIEW (MECHANISM)



## EXPLODED VIEW (UNIT)

Parts with exploded numbers larger than 700 are not supplied



# DP-SE7/SE7(G)/SE9

## PARTS LIST

\* New Parts  
 Parts without **Parts No.** are not supplied.  
 Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.  
 Teile ohne **Parts No.** werden nicht geliefert.

1

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
<b>DP-SE7/SE7(G)</b>						
601	1D		A01-3321-01	METALLIC CABINET		
603	2D		A22-1778-11	SUB PANEL		
604	2C		A29-0872-03	PANEL		
606	2C		A60-1199-13	PANEL	MT1T2E	
606	2C	*	A60-1345-03	PANEL	K	
607	2D		A60-1200-03	PANEL	MT1EK	
607	2D		A60-1298-03	PANEL (GOLD)	T2	
615	2D		B07-2363-04	ESCUTCHEON		
616	2D		B10-2372-03	FRONT GLASS		
617	2C		B12-0318-04	INDICATOR		
-			B46-0328-03	WARRANTY CARD	K	
△ 626	1E		E30-2592-15	AC POWER CORD	ME	
△ 626	1E		E30-2650-05	AC POWER CORD	K	
△ 626	1E		E30-2721-05	AC POWER CORD	T1T2	
628	2D, 2E		E35-1983-05	FLAT CABLE	27P	
629	1E, 2E		E35-1984-05	FLAT CABLE	20P	
630	1E		E35-1985-05	FLAT CABLE	16P	
640	2E		G11-2283-04	CUSHION		
641	2D		G11-2284-04	CUSHION		
642	2D		G11-2342-04	CUSHION		
-			H10-7355-02	POLYSTYRENE FOAMED FIXTURE		
-			H10-7356-02	POLYSTYRENE FOAMED FIXTURE		
-			H12-2359-04	PACKING FIXTURE		
-			H25-1579-04	PROTECTION BAG		
-			H25-1581-04	PROTECTION BAG	T1T2	
-			H25-1620-04	PROTECTION BAG	M	
-			H50-2498-04	ITEM CARTON CASE	MEK	
-		*	H50-2500-04	ITEM CARTON CASE	T1	
-		*	H50-2566-04	ITEM CARTON CASE	T2	
△ 645	2E		J02-0370-05	FOOT		
648	1E		J42-0083-05	POWER CORD BUSHING		
-			J61-0307-05	WIRE BAND	MT1T2E	
650	2D		K29-6743-03	KNOB		
651	2D		K29-6744-04	KNOB	POWER	
△ 655	1E	*	L07-2436-05	POWER TRANSFORMER	M	
△ 655	1E	*	L07-2437-05	POWER TRANSFORMER	T1T2E	
△ 655	1E	*	L07-2505-05	POWER TRANSFORMER	K	
S1			S74-0065-05	LEAF SWITCH		

## DP-SE9

601	1D		A01-3465-01	METALLIC CABINET		
603	1C		A22-1777-01	SUB PANEL		
604	2C		A29-0871-03	PANEL		
606	2C		A60-1266-02	PANEL		
611	1D	*	A50-1303-02	SIDE PLATE		
616	2C		B10-2370-03	FRONT GLASS		
△ 626	1E		E30-2592-15	AC POWER CORD	ME	
△ 626	1E		E30-2721-05	AC POWER CORD	T	
628	2D, 2E		E35-1983-05	FLAT CABLE	27P	
629	1E, 2E		E35-1984-05	FLAT CABLE	20P	

L : Scandinavia  
 Y : PX(Far East, Hawaii)  
 Y : AAFES(Europe)

K : USA  
 T : Europe  
 X : Australia

P : Canada  
 E : Europe  
 M : Other Areas

R : Mexico  
 G : Germany  
 T1 : GRAY  
 T2 : GOLD

\* New Parts  
 Parts without **Parts No.** are not supplied.  
 Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.  
 Teile ohne **Parts No.** werden nicht geliefert.

2

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
630	1E		E35-1985-05	FLAT CABLE	16P	
641	2C		G11-2352-04	CUSHION	PANEL	
642	2C		G11-2325-04	CUSHION	FOOT	
643	2C		G11-2353-04	CUSHION	SIDE PLATE	
-			H10-7353-02	POLYSTYRENE FOAMED FIXTURE		
-		*	H10-7354-02	POLYSTYRENE FOAMED FIXTURE	T	
-		*	H12-2356-04	PACKING FIXTURE	E	
-		*	H25-1579-04	PROTECTION BAG	T	
-		*	H25-1581-04	PROTECTION BAG	M	
-		*	H25-1620-04	PROTECTION BAG	ME	
-		*	H50-2495-04	ITEM CARTON CASE	T	
-		*	H50-2496-04	ITEM CARTON CASE	M	
△ 645	2E		J02-0370-05	FOOT		
648	1E		J42-0083-05	POWER CORD BUSHING		
-			J61-0307-05	WIRE BAND		
651	2C		K29-6741-04	KNOB	POWER	
652	2C		K29-6742-04	KNOB		
653	2C		K29-6766-04	KNOB		
△ 655	1E	*	L07-2436-05	POWER TRANSFORMER	M	
△ 655	1E	*	L07-2437-05	POWER TRANSFORMER	TE	
S1			S74-0065-05	LEAF SWITCH		

## DISPLAY UNIT (X14-45xx-xx)

C1			CE04KW1C332M	ELECTRO	3300UF	16WV		
C2			C90-3209-05	ELECTRO	10UF	6.3WV		
CN1			E40-4632-05	PIN ASSY				
CN2			E40-9965-05	FLAT CABLE CONNECTOR			K	
J1			E03-0148-05	AC OUTLET				
S1	-11		S70-0031-05	TACT SWITCH				
D1			KBP02ML-6127	DIODE				
D2	-7		HSS104	DIODE				
D2	-7		1SS133	DIODE				
D8	,9		HSS104	DIODE				
D8	,9		1SS133	DIODE				
ED1			8-BT-207GK	INDICATOR TUBE				
IC1			ICP-N25	ANALOGUE IC				
A1			W02-2537-05	ELECTRIC CIRCUIT MODULE				
A1			W02-2561-05	ELECTRIC CIRCUIT MODULE			9	

## DECK UNIT (X25-6000-xx)

C1			CE04KW1H101M	ELECTRO	100UF	50WV		
C2			CK73FB1H103K	CHIP C	0.010UF	K		
C3			CE04KW1H100M	ELECTRO	10UF	50WV		
C5			CE04KW1H010M	ELECTRO	1.0UF	50WV		
C6			CE04KW1A221M	ELECTRO	220UF	10WV		
C7			CK73FB1H473K	CHIP C	0.047UF	K		
C8			CE04KW1H010M	ELECTRO	1.0UF	50WV		
C9			CE04KW1A101M	ELECTRO	100UF	10WV		
C10			CE04KW0J331M	ELECTRO	330UF	6.3WV		
C11			CE04KW1A101M	ELECTRO	100UF	10WV		
C12			CE04KW0J331M	ELECTRO	330UF	6.3WV		

L : Scandinavia  
 Y : PX(Far East, Hawaii)  
 Y : AAFES(Europe)

K : USA  
 T : Europe  
 X : Australia

P : Canada  
 E : Europe  
 M : Other Areas

R : Mexico  
 G : Germany  
 T1 : GRAY  
 T2 : GOLD

7 : DP-SE7  
 9 : DP-SE9

△ indicates safety critical components.

## PARTS LIST

4

\* New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

3

Ref. No	Address	New Parts	Parts No.	Description			Desti- nation	Re- marks
C13			CE04KW1A101M	ELECTRO	100UF	10WV		
C14 -16			CK73FB1E104K	CHIP C	0.10UF	K		
C17			CK73FB1H103K	CHIP C	0.010UF	K		
C18 ,19			CC73FSL1H150J	CHIP C	15PF	J		
C20			CK73FB1E104K	CHIP C	0.10UF	K		
C21 -26			CC73FSL1H101J	CHIP C	100PF	J		
C23 -26			CC73FSL1H221J	CHIP C	220PF	J	7	
C27 ,28			CQ93FMG1H272J	MYLAR	2700PF	J	9	
C27 ,28			CQ93FMG1H332J	MYLAR	3300PF	J	7	
C29 ,30			CQ93FMG1H391K	MYLAR	390PF	K		
C31 ,32			C90-3749-05	ELECTRO	47UF	16WV		
C33 ,34			CQ93FMG1H471J	MYLAR	470PF	J		
C35 ,36			CK73FB1H103K	CHIP C	0.010UF	K		
C39			CE04KW0J331M	ELECTRO	330UF	6.3WV	9	
C40			CK73FB1E104K	CHIP C	0.10UF	K	9	
C41			CE04KW1A101M	ELECTRO	100UF	10WV	9	
C42			CK73FB1E104K	CHIP C	0.10UF	K	9	
C43			CK73FB1H103K	CHIP C	0.010UF	K	9	
C44			CE04KW1A101M	ELECTRO	100UF	10WV		
C46			CK73FB1H103K	CHIP C	0.010UF	K		
C47			CK73FB1E104K	CHIP C	0.10UF	K		
C48			CK73FB1H103K	CHIP C	0.010UF	K		
C49			CE04KW1A101M	ELECTRO	100UF	10WV		
C50			CC73FCH1H330J	CHIP C	33PF	J		
C51 ,52			CC73FSL1H221J	CHIP C	220PF	J	9	
C53 ,54			CC73FSL1H221J	CHIP C	220PF	J		
C55			CK73FB1H103K	CHIP C	0.010UF	K		
C56			CC73FSL1H101J	CHIP C	100PF	J		
C57			CC73FSL1H220J	CHIP C	22PF	J	9	
C58 -60			CK73FB1H103K	CHIP C	0.010UF	K		
C61 ,62			CC73FSL1H101J	CHIP C	100PF	J		
CN1			E40-4296-05	FLAT CABLE CONNECTOR				
CN2			E40-9875-05	FLAT CABLE CONNECTOR				
CN3			E40-9966-05	FLAT CABLE CONNECTOR				
J1			E63-0122-05	PHONO JACK				
J2			E08-0312-05	RECTANGULAR RECEPTACLE				
P1			J21-5845-04	MOUNTING HARDWARE				
X1			L77-2217-05	CRYSTAL RESONATOR(16.9344MHZ)				
R1			RK73FB2A472J	CHIP R	4.7K	J 1/10W		
R2			RK73FB2A103J	CHIP R	10K	J 1/10W		
R3 ,4			RK73FB2A181J	CHIP R	180	J 1/10W		
R5			RK73FB2A221J	CHIP R	220	J 1/10W		
R7			RK73FB2A203J	CHIP R	20K	J 1/10W		
R8			RK73FB2A432J	CHIP R	4.3K	J 1/10W		
R9			RK73FB2A181J	CHIP R	180	J 1/10W		
R10			R92-1867-05	METAL	12K	F 1/10W		
R11			R92-1868-05	METAL	4.3K	F 1/10W		
R12			RK73FB2A103J	CHIP R	10K	J 1/10W		
R13			RK73FB2A101J	CHIP R	100	J 1/10W		
R14			RK73FB2A100J	CHIP R	10	J 1/10W		
R15			RK73FB2A221J	CHIP R	220	J 1/10W		
R16			RK73FB2A510J	CHIP R	51	J 1/10W		
R17			RK73FB2A101J	CHIP R	100	J 1/10W		

L : Scandinavia  
Y : PX(Far East, Hawaii)  
Y : AAFES(Europe)

K : USA  
T : Europe  
X : Australia

P : Canada  
E : Europe  
M : Other Areas

R : Mexico  
G : Germany

7 : DP-SE7

9 : DP-SE9

\* New Parts  
Parts without **Parts No.** are not supplied.  
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Address	New Parts	Parts No.	Description			Desti- nation	Re- marks
R18			RK73FB2A103J	CHIP R	10K	J 1/10W		
R19 ,30			RK73FB2A103J	CHIP R	10K	J 1/10W		
R27 ,30			RK73FB2A332J	CHIP R	3.3K	J 1/10W	7	
R31 ,32			RK73FB2A472J	CHIP R	4.7K	J 1/10W	9	
R33 ,34			RK73FB2A152J	CHIP R	1.5K	J 1/10W		
R35 ,36			RK73FB2A103J	CHIP R	10K	J 1/10W		
R37 ,38			RK73FB2A104J	CHIP R	100K	J 1/10W		
R39 ,40			RK73FB2A102J	CHIP R	1.0K	J 1/10W		
R41 ,42			RK73FB2A101J	CHIP R	100	J 1/10W		
R43 ,44			RK73FB2A122J	CHIP R	1.2K	J 1/10W		
R45 ,46			RK73FB2A102J	CHIP R	1.0K	J 1/10W		
R47			RK73FB2A2R2J	CHIP R	2.2	J 1/10W		
R48			RK73FB2A101J	CHIP R	100	J 1/10W	9	
R49			RK73FB2A240J	CHIP R	24	J 1/10W	9	
R50 ,52			RK73FB2A471J	CHIP R	470	J 1/10W	9	
R53 ,56			RK73FB2A472J	CHIP R	4.7K	J 1/10W		
R57			RK73FB2A105J	CHIP R	1.0M	J 1/10W		
R58 ,59			RK73FB2A223J	CHIP R	22K	J 1/10W		
R60 ,61			RK73FB2A472J	CHIP R	4.7K	J 1/10W		
R62 ,74			RK73FB2A473J	CHIP R	47K	J 1/10W		
R75			RK73FB2A104J	CHIP R	100K	J 1/10W		
R76 ,77			RK73FB2A4473J	CHIP R	47K	J 1/10W		
R78 ,79			RK73FB2A4472J	CHIP R	4.7K	J 1/10W		
R80			RK73FB2A103J	CHIP R	10K	J 1/10W		
R81			RK73FB2A473J	CHIP R	47K	J 1/10W		
R82 ,84			RK73FB2A101J	CHIP R	100	J 1/10W		
R85 ,86			RK73FB2A331J	CHIP R	330	J 1/10W		
R87 ,90			RK73FB2A104J	CHIP R	100K	J 1/10W		
R91 ,94			RK73FB2A4472J	CHIP R	4.7K	J 1/10W		
R101-104			RK73FB2A101J	CHIP R	100	J 1/10W	9	
R105			RD14GB2E2R2J	FL-PROOF RD	2.2	J 1/4W		
R106			RD14GB2E1R0J	FL-PROOF RD	1	J 1/4W		
R107,108			RK73FB2A220J	CHIP R	22	J 1/10W		
D1			1SR154-400	DIODE				
D2			UDZ15B	ZENER DIODE				
D3			UDZ13B	ZENER DIODE				
D3			UDZ15B	ZENER DIODE				
D4			UDZ5.1B	ZENER DIODE			7	
D5			UDZ2.7B	ZENER DIODE				
D6 ,7			DA204U	DIODE				
D8 ,9			MA111	DIODE				
D10			DA204U	DIODE				
IC1 ,2			M5237L	ANALOGUE IC				
IC3			PST993D-T	ANALOGUE IC				
IC4			UPD78044FGF071	MI-COM IC				
IC5			KAN03	CUSTOM IC				
IC6			AK4324-VF	MOS-IC				
IC7 ,8			NJM2100M	IC(OP AMPLIFIER)				
IC9			TA8409S	MOS-IC				
Q1			2SA954(L,K)	TRANSISTOR				
Q2			2SB1370	TRANSISTOR				
Q2			2SB1375	TRANSISTOR				
Q3			2SA1534A	TRANSISTOR				
Q4			DTC124EUA	DIGITAL TRANSISTOR				9

L : Scandinavia  
Y : PX(Far East, Hawaii)  
Y : AAFES(Europe)

K : USA  
T : Europe  
X : Australia

P : Canada  
E : Europe  
M : Other Areas

R : Mexico  
G : Germany

7 : DP-SE7  
9 : DP-SE9

L : Scandinavia  
Y : PX(Far East, Hawaii)  
Y : AAFES(Europe)

K : USA  
T : Europe  
X : Australia

P : Canada  
E : Europe  
M : Other Areas

R : Mexico  
G : Germany

7 : DP-SE7  
9 : DP-SE9

△ indicates safety critical components.

## \* New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

5

Ref. No	Address	New Parts	Parts No.	Description	Destination	Remarks
Q4			UN5212	DIGITAL TRANSISTOR		
Q5			2SK246(Y,GR)	FET		
Q7 ,8			2SC2878(B)	TRANSISTOR		
Q9 ,10			DTC124EUA	DIGITAL TRANSISTOR		
Q9 ,10			UN5212	DIGITAL TRANSISTOR		
Q11 ,12			DTA124EUA	DIGITAL TRANSISTOR		
Q11 ,12			UN5112	DIGITAL TRANSISTOR		
Q13 ,14			2SA1586(Y,GR)	TRANSISTOR		
Q13 ,14			2SA1611(M5,M6)	TRANSISTOR		
A1			W02-1114-05	OSCILLATING MODULE		

## CD PLAYER UNIT (X32-3400-00)

C1			CK73FB1H223K	CHIP C	0.022UF	K		
C2			C92-0083-05	CHIP C	47UF	4WV		
C3			CC73FSL1H180J	CHIP C	18PF	J		
C4			CC73FCH1H030C	CHIP C	3.0PF	C		
C5			CK73FB1H103K	CHIP C	0.010UF	K		
C6			CK73FB1H222K	CHIP C	2200PF	K		
C7			CK73FB1H103K	CHIP C	0.010UF	K		
C8			CK73FB1H333K	CHIP C	0.033UF	K		
C9			CK73FB1H103K	CHIP C	0.010UF	K		
C10			CK73FB1H472K	CHIP C	4700PF	K		
C11			C92-0083-05	CHIP C	47UF	4WV		
C12			CC73FSL1H470J	CHIP C	47PF	J		
C13			CK73EB1C474K	CHIP C	0.47UF	K		
C14			CK73EB1C105K	CHIP C	1.0UF	K		
C15 ,16			CK73FB1E104K	CHIP C	0.10UF	K		
C17			C92-0080-05	C ELECTOR	10UF	4WV		
C18			CK73FB1H333K	CHIP C	0.033UF	K		
C19			CK73FB1H102K	CHIP C	1000PF	K		
C20			CC73FSL1H221J	CHIP C	220PF	J		
C21			CK73FB1H473K	CHIP C	0.047UF	K		
C22			CK73FB1H103K	CHIP C	0.010UF	K		
C23			CC73FSL1H101J	CHIP C	100PF	J		
C24			C92-0080-05	C ELECTOR	10UF	4WV		
C25 ,26			CK73FB1H103K	CHIP C	0.010UF	K		
C27			C92-0090-05	CHIP C	22UF	6.3WV		
C28 ,29			CK73FB1E104K	CHIP C	0.10UF	K		
C30			C92-0041-05	CHIP-ELE	10UF	10WV		
C31			CK73FB1H333K	CHIP C	0.033UF	K		
C32			C92-0090-05	CHIP C	22UF	6.3WV		
C33 ,34			CK73FB1E104K	CHIP C	0.10UF	K		
C35 ,36			CK73FB1H102K	CHIP C	1000PF	K		
C37			CK73FB1H473K	CHIP C	0.047UF	K		
C38			CK73FB1H152K	CHIP C	1500PF	K		
C39			CK73FB1H103K	CHIP C	0.010UF	K		
C40			CK73FB1H332K	CHIP C	3300PF	K		
C41			CK73EB1C474K	CHIP C	0.47UF	K		
C42			C92-0090-05	CHIP C	22UF	6.3WV		
C43			CK73FB1E104K	CHIP C	0.10UF	K		
C44			CK73FB1H103K	CHIP C	0.010UF	K		
CN1			E40-9963-05		FLAT CABLE CONNECTOR			
CN2			E40-9964-05		FLAT CABLE CONNECTOR			
CN3			E40-3251-05		PIN ASSY			

L : Scandinavia  
 Y : PX(Far East, Hawaii)  
 Y : AAFES(Europe)

K : USA  
 T : Europe  
 X : Australia

P : Canada  
 E : Europe  
 M : Other Areas

R : Mexico  
 G : Germany

7 : DP-SE7  
 9 : DP-SE9

▲ indicates safety critical components.

## \* New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

6

Ref. No	Address	New Parts	Parts No.	Description			Desti- nation	Re- marks
L1			L40-1001-31	SMALL FIXED INDUCTOR(10UH,K)				
R1			RK73FB2A753J	CHIP R	75K	J	1/10W	
R2			RK73FB2A104J	CHIP R	100K	J	1/10W	
R3 ,4			RK73FB2A203J	CHIP R	20K	J	1/10W	
R5			RK73FB2A472J	CHIP R	4.7K	J	1/10W	
R6			RK73FB2A912J	CHIP R	9.1K	J	1/10W	
R7			RK73FB2A623J	CHIP R	62K	J	1/10W	
R8			RK73FB2A105J	CHIP R	1.0M	J	1/10W	
R9			RK73FB2A224J	CHIP R	220K	J	1/10W	
R10 ,13			RK73FB2A683J	CHIP R	68K	J	1/10W	
R14			RK73FB2A100J	CHIP R	10	J	1/10W	
R15			RK73FB2A332J	CHIP R	3.3K	J	1/10W	
R16			RK73FB2A243J	CHIP R	24K	J	1/10W	
R17			RK73FB2A392J	CHIP R	3.9K	J	1/10W	
R18			RK73FB2A101J	CHIP R	100	J	1/10W	
R19			RK73FB2A102J	CHIP R	1.0K	J	1/10W	
R20 ,21			RK73FB2A334J	CHIP R	330K	J	1/10W	
R22			RK73FB2A473J	CHIP R	47K	J	1/10W	
R23			RK73FB2A101J	CHIP R	100	J	1/10W	
R24			RK73FB2A392J	CHIP R	3.9K	J	1/10W	
R25			RK73FB2A682J	CHIP R	6.8K	J	1/10W	
R26			RK73FB2A155J	CHIP R	1.5M	J	1/10W	
R27			RK73FB2A223J	CHIP R	22K	J	1/10W	
R28			RK73FB2A684J	CHIP R	680K	J	1/10W	
R29			RK73FB2A105J	CHIP R	1.0M	J	1/10W	
R30 ,31			RK73FB2A124J	CHIP R	120K	J	1/10W	
R32			RK73FB2A155J	CHIP R	1.5M	J	1/10W	
R33			RK73FB2A514J	CHIP R	510K	J	1/10W	
R34			RK73FB2A282J	CHIP R	82K	J	1/10W	
R35			RK73FB2A104J	CHIP R	100K	J	1/10W	
R36			RK73FB2A223J	CHIP R	22K	J	1/10W	
R37			RK73FB2A183J	CHIP R	18K	J	1/10W	
R38			RK73FB2A104J	CHIP R	100K	J	1/10W	
R39			RK73FB2A244J	CHIP R	240K	J	1/10W	
R40			RK73FB2A184J	CHIP R	180K	J	1/10W	
R41 ,42			RK73FB2A472J	CHIP R	4.7K	J	1/10W	
R43			RK73FB2A562J	CHIP R	5.6K	J	1/10W	
R44			RK73FB2A102J	CHIP R	1.0K	J	1/10W	
R45			RK73FB2A104J	CHIP R	100K	J	1/10W	
R46			RK73FB2A332J	CHIP R	3.3K	J	1/10W	
R47			RK73FB2A103J	CHIP R	10K	J	1/10W	
R48			RK73FB2A332J	CHIP R	3.3K	J	1/10W	
R49			RK73FB2A105J	CHIP R	1.0M	J	1/10W	
R50			RK73FB2A104J	CHIP R	100K	J	1/10W	
R51 ,53			RK73FB2A471J	CHIP R	470	J	1/10W	
R54			RK73FB2A472J	CHIP R	4.7K	J	1/10W	
R55			RK73FB2A101J	CHIP R	100	J	1/10W	
R56			RK73FB2A688J	CHIP R	6.8	J	1/10W	
R57			RK73FB2A121J	CHIP R	120	J	1/10W	
R58			RK73FB2A688J	CHIP R	6.8	J	1/10W	
VR1			R32-0049-05	SEMI FIXED VARIABLE RESISTOR				
VR2			R32-0048-05	SEMI FIXED VARIABLE RESISTOR				
VR3			R32-0049-05	SEMI FIXED VARIABLE RESISTOR				

L : Scandinavia  
 Y : PX(Far East, Hawaii)  
 Y : AAFES(Europe)

K : USA  
 T : Europe  
 X : Australia

P : Canada  
 E : Europe  
 M : Other Areas

R : Mexico  
 G : Germany

7 : DP-SE7  
 9 : DP-SE9

▲ indicates safety critical components.

6

**PARTS LIST**

**DP-SE7/SE7(G)/SE9**

# DP-SE7/SE7(G)/SE9

## PARTS LIST

7

\* New Parts  
Parts without **Parts No.** are not supplied.  
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.  
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
D1 - 4			MA111	DIODE		
D5			DA204U	DIODE		
IC1			CXA1782BQ <sup>1</sup>	ANALOGUE IC		
IC2			CXD2507AQ <sup>1</sup>	MOSIC		
IC3			BA6398FP	ANALOGUE IC		
Q1			2SC4081(R,S)	TRANSISTOR		
Q2			2SA1586(Y,GR)	TRANSISTOR		
Q2			2SA1611(M5,M6)	DIGITAL TRANSISTOR		
Q3	4		DTA124EUA	DIGITAL TRANSISTOR		
Q3	4		UN5112	DIGITAL TRANSISTOR		
<b>MECHANISM (D40-1571-05)</b>						
1	2B	A10-3325-08	CHASSIS			
3	2A	D10-3685-08	SHAFT(TABLE GUIDE)			
5	3A	D10-3686-08	SLID SHAFT			
6	1A	D12-0156-08	CAM	(P)		
7	1A	D13-1793-08	GEAR	(A)(S)		
10	2A	D13-1796-08	GEAR	(B)(RP)		
11	3A	D13-1797-08	GEAR			
12	1A	D16-0713-08	BELT			
13	2A	D23-0328-08	BEARING			
15	2B	E40-8051-08	PIN CONNECTOR (PC BORD),5P			
20	3A	G01-3989-08	SPRING (S) COMPRESSION			
25	3A	J02-1179-08	PURBER VIBRATION			
26	3A	J02-1180-08	PURBER VIBRATION			
27	1A	J19-5768-08	HOLDER (MG)(K) ASSY			
28	2A	J19-5769-08	HOLDER (BU) ASSY			
29	2B	J70-0995-08	PC BORD LOADING			
30	3A	J90-0846-08	RING (LO)(S) CENTER			
31	2A	J99-0992-08	TABLE DISK			
	BB	N09-3345-08	SCREW	(2,6X16)		
	FF	N87-3010-46	SCREW TAPPING	(3X10)		
40	2B	S74-0075-08	SWITCH LEAF			
45	3B	T25-0061-08	PICKUP ASSY	KSS-213C(R)		
46	2B	T42-0873-08	MOTOR ASSY,LOADING			
47	3A	T42-0907-08	MOTOR CHASSIS ASSY(MB)			
48	3A	T42-0875-08	MOTOR GEAR ASSY(MB)			

## SPECIFICATIONS

### CD player (DP-SE9)

Laser	Semiconductor laser
Playing rotation	200 rpm ~ 500 rpm (CLV)
Frequency response	4 Hz ~ 20 kHz, ± 1.0 dB
Signal to noise ratio	More than 100 dB
Dynamic range	More than 95 dB
Total harmonic distortion	Less than 0.004 % (at 1 kHz)
Channel separation	More than 92 dB (at 1 kHz)
Wow & Flutter	Unmeasurable Limit
Output level / impedance	
Fixed	1.2 V / 1 kΩ
Digital output	
Optical	-15 dBm ~ -21 dBm (wave length 660 nm)

### General

Power consumption	10 W
Dimensions	W : 213 mm H : 97 mm D : 249 mm
Weight (net)	2.2 kg

 1. KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.  
2. Sufficient performance may not be exhibited at extremely cold locations (where water freezes.).

### Note:

Component and circuit are subject to modification to insure best operation under differing local conditions. This manual is based on Europe (E) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

### CD player (DP-SE7)

Laser	Semiconductor laser
Playing rotation	200 rpm ~ 500 rpm (CLV)
Frequency response	4 Hz ~ 20 kHz, ± 1.0 dB
Signal to noise ratio	More than 100 dB
Dynamic range	More than 96 dB
Total harmonic distortion	Less than 0.004 % (at 1 kHz)
Channel separation	More than 92 dB (at 1 kHz)
Wow & Flutter	Unmeasurable Limit
Output level / impedance	
Fixed	1.2 V / 1 kΩ
Digital output	
Optical	-15 dBm ~ -21 dBm (wave length 660 nm)

### General

Power consumption	10 W
Dimensions	W : 200 mm H : 77 mm D : 249 mm
Weight (net)	2.0 kg

L: Scandinavia  
P: Canada  
K: USA  
Y: PX(Far East, Hawaii)  
V: AA(FSEurope)  
T: Europe  
E: Europe  
X: Australia  
R: Mexico  
G: Germany  
M: Other Areas  
7: DP-SE7  
9: DP-SE9  
△ indicates safety critical components.